GAS TEMPERATURE SENSOR

MODEL R000 (For laboratory use) MODEL R011 (For general industrial use)

MODEL R030 (For general indoor use) MODEL R031 (For general indoor use)



MODEL R000

These small and light weight sensors are designed to measure temperature of gas/air, suitable for temperature measurement in thermostatic bath, drying chambers, artificial environment and climate chambers.

■ GENERAL SPECIFICATIONS

NET-TUBE TYPE (R000-31, R000-31W)

Resistance element: Pt100, (3-wire type)

*Please contact us for JPt100

JIS B, A Class:

Rated current: 2mA (Specify if 1mA)

Temperature range: -30 to 130°C (heat-conductive part is up to 60°C)

Material of protective tube:

Nickel-plated brass (Removable)

Dimension of protective tube:

12mm x 100mm Lead wire:

Single element type.....

Vinyl coated 3-core copper lead wire,

meter length

(When specified heat-coated copper lead wire, silicon coated 3-core copper lead wire (180°C heat-resistant), type WS36, outer diameter *ϕ*6mm is used

instead.)

Double element type.....

Vinyl coated 6-core copper lead wire,

type WV61, outer diameter ϕ 10mm, 3

meter length

(When specified heat-coated copper lead wire, silicon coated 6-core copper lead wire (180°C heat-resistant), type

WS68, outer diameter *φ*8mm is used

instead.)

Mounting: Wall mount

CLOSED-TUBE TYPE (R000-32, R000-32W)

Resistance element: Pt100, (3-wire type)

*Please contact us for JPt100

JIS B, A Class:

Rated current: Pt100.....2mA (Specify if 1mA)

Temperature range: -50 to 150°C (heat-conductive part is up to 60°C)

Material of protective tube: SUS304

Dimension of protective tube:

*φ*6mm x 100mm Lead wire: Single element type.....

Vinyl coated 3-core copper lead wire,

type WV38, outer diameter φ8mm, 3

meter length

(When specified heat-coated copper lead wire, silicon coated 3-core copper lead wire (180°C heat-resistant), type WS36, outer diameter ϕ 6mm is used

instead.) Double element type.....

Vinyl coated 6-core copper lead wire, type WV61, outer diameter ϕ 10mm, 3

meter length

(When specified heat-coated copper lead wire, silicon coated 6-core copper lead wire (180°C heat-resistant), type

instead.)

Mounting: Wall mount

RESPONSE TIME

In the air (50°C→20°C): Net-tube type Approx.70 seconds


Closed-tube Approx.3 minutes (Note: This response time means the time to reach 63.2% of the equilibrium

value.)



MODEL R000-31


MODEL



Blank: Single element type W: Double element type


EXTERNAL DIMENSIONS

NET-TUBE TYPE (R000-31, R000-31W)



*Conductor allowable temperature -20 to 60°C

CLOSED-TUBE TYPE (R000-32, R000-32W)



*Conductor allowable temperature -20 to 60°C

Unit: mm

GAS TEMPERATURE SENSOR

MODEL R011

These sensors are suitable for temperature management of industrial use at general production work room and warehouse.

GENERAL SPECIFICATIONS

Resistance element: Pt100 (3-wire type)

*Please contact us for JPt100

JIS B, A Class:

Rated current: 2mA (Specify if 1mA)

Temperature range: -20 to 60℃ Material of protective tube: SUS304 Dimension of protective tube:

φ6mm x 100mm Single element type..... Lead wire:

Vinyl coated 3-core copper lead wire,

meter length Double element type.....

Vinyl coated 6-core copper lead wire,

meter length

Mounting: Wall mount

RESPONSE TIME


In the air (50°C→20°C):

Approx.50 seconds (This response time means the time to reach 63.2% of the equilibrium value.)




MODEL R011-1

MODEL



Blank: Single element type W: Double element type

EXTERNAL DIMENSIONS



Unit: mm



MODEL R030

These small, lightweight and high responses are designed to measure temperature of gas/air, suitable for temperature management at high humidity place or freezer compartment because of the waterproof structure.

GENERAL SPECIFICATIONS

Resistance element: Pt100 (3-wire type)
*Please contact us for JPt100

JIS B, A Class:

Rated current: 2mA (Specify if 1mA)

Temperature range: -30 to 100°C Material of protective tube: SUS304 Dimension of protective tube:

φ2.5mm (0.2mm wall thickness)Single element type.....

Lead wire:

Vinyl coated 3-core copper lead wire, type WV35, outer diameter ϕ 5mm, 3

meter length Double element type.....

Use 2 pcs. same wire of the above.

Mounting: Wall mount

Casing: Structure.....Drip-proof type

Material......Heat-resistant ABS resin

Color.....Cream

RESPONSE TIME


In the air (50°C→20°C): Approx.25 seconds

(This response time means the time to reach 63.2% of the equilibrium value.)




MODEL R030-3W

MODEL




Blank: Single element type W: Double element type

EXTERNAL DIMENSIONS



MOUNTING FIGURE



Unit: mm



MODEL R031

This is for general indoor use, suitable for room temperature measurement in relatively severe air conditioning management as pharmaceutical plant or blood storage center.

Since it has good response, the mounting has become easier to set up on the wall according to JIS standards. Thermo-plate type is available for to lessen the effect of wall surface temperature.

GENERAL SPECIFICATIONS

Resistance element: Pt100 (3-wire type)

Class: JIS A Rated current: 1mA Temperature range: -20 to 80℃

Natural draft type-heat-resistant ABS resin Casing:

material (Color: Munsell N9)

Lead wire connection:

Terminal connection (Please prepare the lead

wire separately)

Wall mount, mounting hole pitch 66.7mm (Correspond to JIS C 8340 standard product) Mounting:

Complies with RoHS


RESPONSE TIME

In the air $(50^{\circ}\text{C} \rightarrow 20^{\circ}\text{C})$: Approx.50 seconds


(This response time means the time to reach 63.2% of the equilibrium value.)


EXTERNAL DIMENSIONS





TERMINAL ARRANGEMENT






MODEL R031-3T

MODEL R031−3 □ THERMOPLATE

> Blank : Standard type : With thermoplate



Specifications subject to change without notice. Printed in Japan (I) 2015.8

CHINO CORPORATION

32-8 KUMANO-CHO, ITABASHI-KU, TOKYO 173-8632

Telephone: +81-3-3956-2171 Facsimile: +81-3-3956-0915 E-mail: inter@chino.co.jp Website: www.chino.co.jp/